

[Reference](http://www.ti.com.cn/tool/tida-01373?dcmp=dsproject&hqs=rd) Design

TEXAS INSTRUMENTS

[DRV10983](http://www.ti.com.cn/product/cn/drv10983?qgpn=drv10983), DRV10983Z

ZHCSDA7G –JULY 2014–REVISED FEBRUARY 2018

DRV1098312V 至 **24V** 三相无传感器 **BLDC** 电机驱动器

1 特性

- ¹• 输入电压范围:8 至 28V
- 总驱动器 H + L $r_{DS(on)}$: 250mΩ
- 驱动电流: 2A 持续绕组电流 (峰值 3A)
- 无传感器专有反电动势 (BEMF) 控制方案
- 连续正弦 180° 换向
- 无需外部感测电阻
- 用户可通过添加外部感应电阻以灵活监视为电机提 供的功率
- 灵活的用户接口选项:
	- I²C 接口: 访问命令和反馈寄存器
	- 专用的 SPEED 引脚:接受模拟或 PWM 输入
	- 专用的 FG 引脚: 提供 TACH 反馈
	- 可通过 EEPROM 定制旋转曲线 – 使用 DIR 引脚进行正向/反向控制
- 集成了降压稳压器,可高效地为内部和外部电路提 供电压 (5V 或 3.3V)
- • 电源电流为 3mA 待机型号 (DRV10983)
- • 电源电流为 180 μA 睡眠型号 (DRV10983Z)
- 过流保护
- 锁定检测
- 电压浪涌保护
- 欠压闭锁 (UVLO) 保护
- 热关断保护
- • 耐热增强型 24 引脚散热薄型小外形尺寸 (HTSSOP)
- **2** 应用
- 设备风扇
- 制热、通风与空调控制 (HVAC)

3 说明

DRV10983 器件是一款具有集成功率 MOSFET 的三相 无传感器电机驱动器,可提供高达 2A 的持续驱动电 流。该器件专为成本敏感型、低噪声、低外部组件数量 应用而设计低功耗是一个关键问题。

DRV10983 器件采用专有无传感器控制方案来提供持 续正弦驱动,可大幅降低换向过程中通常会产生的纯 音。该器件的接口设计简单而灵活。可直接通过 PWM、模拟、或 I ²C 输入控制电机。可通过 FG 引脚 或 I2C 提供电机速度反馈。

DRV10983器件 安全功能包括 一个集成降压稳压器, 可高效地将电源电压降至 5V 或 3.3V,从而为内外部 电路供电。该器件提供睡眠模式和待机模式两种型号, 可在电机停止运转时实现节能。待机模式 (3mA) 型号 会使稳压器保持运行,而休眠模式 (180μA) 型号会使 稳压器停止工作。在使用稳压器 为外部 微控制器供电 的应用中使用待机模式型号。

(1) 要了解所有可用封装,请参阅数据表末尾的可订购产品附录。

应用电路原理图

[DRV10983,](http://www.ti.com.cn/product/cn/drv10983?qgpn=drv10983) DRV10983Z

ZHCSDA7G –JULY 2014–REVISED FEBRUARY 2018 **www.ti.com.cn**

8.2 Functional Block Diagram [12](#page-11-0) 8.3 Feature Description... [13](#page-12-0) 8.4 Device Functional Modes.. [16](#page-15-0)

目录

4 修订历史记录

注:之前版本的页码可能与当前版本有所不同。

Changes from Revision E (May 2017) to Revision F Page

Changes from Revision D (May 2017) to Revision E Page

版权 © 2014–2018, Texas Instruments Incorporated

EXAS **STRUMENTS**

www.ti.com.cn ZHCSDA7G –JULY 2014–REVISED FEBRUARY 2018

Changes from Revision B (February 2015) to Revision C Page

XAS

STRUMENTS

• Added "phase to phase" clarification for overcurrent protection... [9](#page-8-1) • Added more accurate description to clarify overcurrent protection operation .. [14](#page-13-0)

Changes from Revision A (October 2014) to Revision B Page

Changes from Original (July 2014) to Revision A Page

5 说明 (续)

用户可通过 I2C 接口对寄存器中的特定电机参数进行重新编程并可对 EEPROM 进行编程, 以帮助优化既定应用的 性能。DRV10983 器件采用带有外露散热焊盘的高效散热型 HTSSOP 24 引脚封装。额定工作温度为 –40°C 至 125°C。

6 Pin Configuration and Functions

Pin Functions

(1) $I = input$, $O = output$, $I/O = input/output$, $P = power$

www.ti.com.cn ZHCSDA7G –JULY 2014–REVISED FEBRUARY 2018

Pin Functions (continued)

7 Specifications

7.1 Absolute Maximum Ratings

over operating ambient temperature (unless otherwise noted)⁽¹⁾

(1) Stresses beyond those listed under *Absolute Maximum Ratings* may cause permanent damage to the device. These are stress ratings only, which do not imply functional operation of the device at these or any other conditions beyond those indicated under *Recommended Operating Conditions*. Exposure to absolute-maximum-rated conditions for extended periods may affect device reliability.

(2) All voltage values are with respect to the network ground terminal unless otherwise noted.

7.2 ESD Ratings

(1) JEDEC document JEP155 states that 500-V HBM allows safe manufacturing with a standard ESD control process.

(2) JEDEC document JEP157 states that 250-V CDM allows safe manufacturing with a standard ESD control process.

[DRV10983,](http://www.ti.com.cn/product/cn/drv10983?qgpn=drv10983) DRV10983Z

ZHCSDA7G –JULY 2014–REVISED FEBRUARY 2018 **www.ti.com.cn**

ISTRUMENTS

EXAS

7.3 Recommended Operating Conditions

over operating ambient temperature range (unless otherwise noted)

7.4 Thermal Information

(1) For more information about traditional and new thermal metrics, see the *[Semiconductor](http://www.ti.com/cn/lit/pdf/spra953) and IC Package Thermal Metrics* application [report.](http://www.ti.com/cn/lit/pdf/spra953)

7.5 Electrical Characteristics

over operating ambient temperature range (unless otherwise noted)

ZHCSDA7G –JULY 2014–REVISED FEBRUARY 2018 **www.ti.com.cn**

Texas
Instruments

Electrical Characteristics (continued)

over operating ambient temperature range (unless otherwise noted)

Electrical Characteristics (continued)

over operating ambient temperature range (unless otherwise noted)

[DRV10983,](http://www.ti.com.cn/product/cn/drv10983?qgpn=drv10983) DRV10983Z ZHCSDA7G –JULY 2014–REVISED FEBRUARY 2018 **www.ti.com.cn**

EXAS STRUMENTS

7.6 Typical Characteristics

8 Detailed Description

8.1 Overview

The DRV10983 is a three-phase sensorless motor driver with integrated power MOSFETs, which provide drive current capability up to 2 A continuous. The device is specifically designed for low-noise, low external component count, 12- to 24-V motor drive applications. The device is configurable through a simple I²C interface to accommodate different motor parameters and spin-up profiles for different customer applications.

A 180° sensorless control scheme provides continuous sinusoidal output voltages to the motor phases to enable ultra-quiet motor operation by keeping the electrically induced torque ripple small.

The DRV10983 features extensive protection and fault detect mechanisms to ensure reliable operation. Voltage surge protection prevents the input Vcc capacitor from overcharging, which is typical during motor deceleration. The devices provides phase to phase overcurrent protection without the need for an external current sense resistor. Rotor lock detect is available through several methods. These methods can be configured with register settings to ensure reliable operation. The device provides additional protection for undervoltage lockout (UVLO) and for thermal shutdown.

The commutation control algorithm continuously measures the motor phase current and periodically measures the VCC supply voltage. The device uses this information for BEMF estimation, and the information is also provided through the I²C register interface for debug and diagnostic use in the system, if desired.

A buck step-down regulator efficiently steps down the supply voltage. The output of this regulator provides power for the internal circuits and can also be used to provide power for an external circuit such as a microcontroller. If providing power for an external circuit is not necessary (and to reduce system cost), configure the buck stepdown regulator as a linear regulator by replacing the inductor with resistor.

TI designed the interfacing to the DRV10983 to be flexible. In addition to the I^2C interface, the system can use the discrete FG pin, DIR pin, and SPEED pin. SPEED is the speed command input pin. It controls the output voltage amplitude. DIR is the direction control input pin. FG is the speed indicator output, which shows the frequency of the motor commutation.

EEPROM is integrated in the DRV10983 as memory for the motor parameter and operation settings. EEPROM data transfers to the register after power on and exit from sleep mode.

The DRV10983 device can also operate in register mode. If the system includes a microcontroller communicating through the I²C interface, the device can dynamically update the motor parameter and operation settings by writing to the registers. In this configuration, the EEPROM data is bypassed by the register settings.

[DRV10983,](http://www.ti.com.cn/product/cn/drv10983?qgpn=drv10983) DRV10983Z

ZHCSDA7G –JULY 2014–REVISED FEBRUARY 2018 **www.ti.com.cn**

NSTRUMENTS

Texas

8.2 Functional Block Diagram

8.3 Feature Description

8.3.1 Regulators

8.3.1.1 Step-Down Regulator

The DRV10983 includes a hysteretic step-down voltage regulator that can be operated as either a switching buck regulator using an external inductor or as a linear regulator using an external resistor (see [图](#page-12-2) 4). The best efficiency is achieved when the step-down regulator is in buck mode. However, the DRV10983Z device (sleep mode version) only operates with the step-down regulator in linear mode and with a Zener diode as described in the *Typical [Application](#page-46-2)* section. The regulator output voltage can be configured by register bit VregSel. When VregSel = 0, the regulator output voltage is 5 V, and when VregSel = 1, the regulator output voltage is 3.3 V. When the regulated voltage drops by the hysteresis level, the high-side FET turns on to increase the regulated voltage back to the target of 3.3 V or 5 V. The switching frequency of the hysteretic regulator is not constant and changes with the load.

If the step-down regulator is configured in buck mode, see I_{REG MAX} in the *Electrical [Characteristics](#page-6-0)* to determine the amount of current provided for external load. If the step-down regulator is configured as linear mode, it is used for the device internal circuit only.

> 注 The DRV10983Z step-down regulator only operates in linear mode (using an external resistor) and with a Zener diode as described in the *Typical [Application](#page-46-2)* section. The DRV10983Z device does not support buck mode (using an external inductor) as shown in [图](#page-12-2) 4.

Step-Down Regulator With External Inductor (Buck Mode)

Step-Down Regulator With External Resistor (Linear Mode)

图 **4. Step-Down Regulator Configurations**

8.3.1.2 3.3-V and 1.8-V LDO

The DRV10983 includes a 3.3-V LDO and an 1.8-V LDO. The 1.8-V LDO is for internal circuit only. The 3.3-V LDO is mainly for internal circuits, but can also drive external loads not to exceed I_{V3P3} _{MAX} listed in the *[Electrical](#page-6-0) [Characteristics](#page-6-0)*. For example, it can work as a pullup voltage for the FG, DIR, SDA, and SCL interface.

Both V1P8 and V3P3 capacitor must be connected to GND.

8.3.2 Protection Circuits

8.3.2.1 Thermal Shutdown

The DRV10983 has a built-in thermal shutdown function, which shuts down the device when junction temperature is more than T_{SDN} °C and recovers operating conditions when junction temperature falls to T_{SDN} – $T_{SDN HYS}$ °C.

The OverTemp status bit (address 0x10 bit 7) is set during thermal shutdown.

Feature Description (接下页**)**

8.3.2.2 Undervoltage Lockout (UVLO)

The DRV10983 has a built-in UVLO function block. The hysteresis of UVLO threshold is $V_{UVLO-HYS}$. The device is locked out when VCC is down to V_{UVLO F} and woke up at V_{UVLO R}.

8.3.2.3 Overcurrent Protection (OCP)

The overcurrent protection function acts to protect the device if the current, as measured from the FETs, exceeds the $I_{OC-limit}$ threshold. It protects the device from phase-to-phase short-circuit conditions; the DRV10983 places the output drivers into a high-impedance state and maintains this condition until the overcurrent is no longer present. The OverCurr status bit (address 0x10 bit 5) is set.

The DRV10983 also provides acceleration current limit and lock detection current limit functions to protect the device and motor (see *[Current](#page-30-0) Limit* and *Lock Detect and Fault [Handling](#page-31-0)*).

8.3.2.4 Lock

When the motor is blocked or stopped by an external force, the lock protection is triggered, and the device stops driving the motor immediately. After the lock release time $t_{\text{LOCK OFF}}$, the DRV10983 resumes driving the motor again. If the lock condition is still present, it enters the next lock protection cycle until the lock condition is removed. With this lock protection, the motor and device does not get overheated or damaged due to the motor being locked (see *Lock Detect and Fault [Handling](#page-31-0)*).

During lock condition, the MtrLck Status bit (address 0x10, bit 4) is set. To further diagnose, check the register FaultCode.

8.3.3 Motor Speed Control

The DRV10983 offers four methods for indirectly controlling the speed of the motor by adjusting the output voltage amplitude. This can be accomplished by varying the supply voltage (V_{CC}) or by controlling the Speed Command. The Speed Command can be controlled in one of three ways. The user can set the Speed Command on the SPEED pin by adjusting either the PWM input (SPEED pin configured for PWM mode) or the analog input (SPEED pin configured for analog mode), or by writing the Speed Command directly through the I²C serial port to SpdCtrl[8:0]. The Speed Command is used to determine the PWM duty cycle output (PWM_DCO) (see $\overline{\otimes}$ 5).

The Speed Command may not always be equal to the PWM_DCO because DRV10983 has implemented the AVS function (see *AVS [Function](#page-34-0)*), the acceleration current limit function (see *[Acceleration](#page-31-1) Current Limit*), and the closed loop accelerate function (see *Closed Loop [Accelerate](#page-28-3)*) to optimize the control performance. These functions can limit the PWM_DCO, which affects the output amplitude.

图 **5. Multiplexing the Speed Command to the Output Amplitude Applied to the Motor**

The output voltage amplitude applied to the motor is accomplished through sine wave modulation so that the phase-to-phase voltage is sinusoidal.

Feature Description (接下页**)**

When any phase is measured with respect to ground, the waveform is sinusoidally coupled with third-order harmonics. This encoding technique permits one phase to be held at ground while the other two phases are pulse-width modulated. [图](#page-14-1) 6 and 图 7 show the sinusoidal encoding technique used in the DRV10983.

Sinusoidal voltage from phase to phase Sinusoidal voltage with third order harmonics from phase to GND

图 **7. Representing Sinusoidal Voltages With Third-Order Harmonic Output**

The output amplitude is determined by the magnitude of V_{CC} and the PWM duty cycle output (PWM_DCO). The PWM_DCO represents the peak duty cycle that is applied in one electrical cycle. The maximum amplitude is reached when PWM_DCO is at 100%. The peak output amplitude is V_{CC} . When the PWM_DCO is at 50%, the peak amplitude is V_{CC} / 2 (see \boxtimes 8).

图 **8. Output Voltage Amplitude Adjustment**

8.3.4 Sleep or Standby Condition

The DRV10983 is available in either a sleep mode or standby mode version. The DRV10983 enters either sleep or standby to conserve energy. When the device enters either sleep or standby, the motor stops driving. The step-down regulator is disabled in the sleep mode version to conserve more energy. The I²C interface is disabled and any register data not stored in EEPROM will be reset. The step-down regulator remains active in the standby mode version. The register data is maintained, and the I²C interface remains active.

Setting sleepDis = 1 prevents the device from entering into the sleep or standby condition. If the device has already entered into sleep or standby condition, setting sleepDis = 1 will not take it out of the sleep or standby condition. During a sleep or standby condition, the Slp_Stdby status bit (address 0x10, bit 6) will be set.

版权 © 2014–2018, Texas Instruments Incorporated

Feature Description (接下页**)**

For different speed command modes, $\frac{1}{3}$ 1 shows the timing and command to enter the sleep or standby condition.

表 **1. Conditions to Enter or Exit Sleep or Standby Condition**

Note that using the analog speed command, a higher voltage is required to exit from the sleep condition than the standby condition. The I^2C speed command cannot take the device out of the sleep condition because I^2C communication is disabled during the sleep condition.

8.3.5 Non-Volatile Memory

The DRV10983 has 96-bits of EEPROM data, which are used to program the motor parameters as described in the *I ²C Serial [Interface](#page-40-3)*.

The procedure for programming the EEPROM is as follows. TI recommends to perform the EEPROM programming without the motor spinning, power cycle after the EEPROM write, and read back the EEPROM to verify the programming is successful.

- 1. Set SIdata $= 1$.
- 2. Write the desired motor parameters into the corresponding registers (address 0x20:0x2B) (see *I ²C [Serial](#page-40-3) [Interface](#page-40-3)*).
- 3. Write 1011 0110 (0xB6) to enProgKey in the DevCtrl register.
- 4. Ensure that V_{CC} is at or above 22 V.
- 5. Write eeWrite = 1 in EECtrl register to start the EEPROM programming.

The programming time is about 24 ms, and eeWrite bit is reset to 0 when programming is done.

8.4 Device Functional Modes

This section includes the logic required to be able to reliably start and drive the motor. It describes the processes used in the logic core and provides the information needed to effectively configure the parameters to work over a wide range of applications.

8.4.1 Motor Parameters

For the motor parameter measurement, see the *DRV10983 and [DRV10975](http://www.ti.com/cn/lit/pdf/SLOU395) Tuning Guide*.

The motor phase resistance and the BEMF constant (Kt) are two important parameters used to characterize a BLDC motor. The DRV10983 requires these parameters to be configured in the register. The motor phase resistance is programmed by writing the values for Rm[6:0] in the MotorParam1 register. The BEMF constant is programmed by writing the values for Kt[6:0] in the MotorParam2 register.

8.4.1.1 Motor Phase Resistance

For a wye-connected motor, the motor phase resistance refers to the resistance from the phase output to the center tap, R_{PH-CT} (see $\boxed{8}$ 9).

Device Functional Modes (接下页**)**

图 **9. Wye-Connected Motor Phase Resistance**

For a delta-connected motor, the motor phase resistance refers to the equivalent phase to center tap in the wye configuration, which is represented as R_Y . $R_{PHCT} = R_Y$ (see \boxtimes [10\)](#page-16-1).

For both the delta-connected motor and the wye-connected motor, calculating the equivalent R_{PH-CT} is easy by measuring the resistance between two phase terminals (R_{PH-PH}) , and then dividing this value by two as shown in [公式](#page-16-2) 1.

 $R_{PH\ CT} = \frac{1}{2}R_{PH\ PH}$ (1)

图 **10. Delta-Connected Motor and the Equivalent Wye Connections**

The motor phase resistance (R_{PH CT}) must be converted to a 7-bit digital register value Rm[6:0] to program the motor phase resistance value. The digital register value can be determined as follows:

- 1. Convert the motor phase resistance ($R_{PH\ CT}$) to a digital value where the LSB is weighted to represent 9.67 mΩ: Rmdig = R_{PHCT} / 0.00967.
- 2. Encode the digital value such that Rm dig = Rm [3:0] << Rm [6:4].

The maximum resistor value, R_{PH CT}, that can be programmed for the DRV10983 is 18.5 Ω , which represents Rmdig = 1920 and an encoded Rm[6:0] value of 0x7Fh. The minimum resistor the DRV10983 supports is 0.029 Ω , R_{PH CT}, which represents Rmdig = 3.

Device Functional Modes (接下页**)**

For convenience, the encoded value for Rm[6:0] can also be obtained from $\frac{1}{\sqrt{2}}$ 2.

表 **2. Motor Phase Resistance Look-Up Table**

8.4.1.2 BEMF Constant

The BEMF constant, Kt[6:0] describes the motors phase-to-phase BEMF voltage as a function of the motor velocity.

The measured BEMF constant (Kt) needs to be converted to a 7-bit digital register value Kt[6:0] to program the BEMF constant value. The digital register value can be determined as follows:

- 1. Convert the measured Kt to a weighted digital value: $Kt_{ph_dig} = 1090 \times Kt$
- 2. Encode the digital value such that $Kt_{ph_dig} = Kt[3:0] \ll Kt[4:6]$.

The maximum Kt that can be programmed is 1760 mV/Hz. This represents a digital value of 1920 and an encoded Kt[6:0] value of 0x7Fh. The minimum Kt that can be programmed is 0.92 mV/Hz, which represents a digital value of 1 and an encoded Kt[6:0] value of 0x01h.

For convenience, the encoded value of Kt[6:0] may also be obtained from $\frac{1}{3}$.

表 **3. BEMF Constant Look-Up Table**

8.4.2 Starting the Motor Under Different Initial Conditions

The motor can be in one of three states when the DRV10983 attempts to begin the start-up process. The motor may be stationary, or spinning in the forward or reverse directions. The DRV10983 includes a number of features to allow for reliable motor start under all of these conditions. \mathbb{R} [11](#page-19-1) shows the motor start-up flow for each of the three initial motor states.

8.4.2.1 Case 1 – Motor Is Stationary

If the motor is stationary, the commutation logic must be initialized to be in phase with the position of the motor. The DRV10983 provides for two options to initialize the commutation logic to the motor position. Initial position detect (IPD) determines the position of the motor based on the deterministic inductance variation, which is often present in BLDC motors. The Align and Go technique forces the motor into alignment by applying a voltage across a particular motor phase to force the motor to rotate in alignment with this phase. The following sections explain how to configure these techniques for use in the designer's system.

8.4.2.2 Case 2 – Motor Is Spinning in the Forward Direction

If the motor is spinning forward with enough velocity, the DRV10983 may be configured to go directly into closed loop. By resynchronizing to the spinning motor, the user achieves the fastest possible start-up time for this initial condition.

8.4.2.3 Case 3 – Motor Is Spinning in the Reverse Direction

If the motor is spinning in the reverse direction, the DRV10983 provides several methods to convert it back to forward direction.

One method, reverse drive, allows the motor to be driven so that it accelerates through zero velocity. The motor achieves the shortest possible spin-up time in systems where the motor is spinning in the reverse direction.

If this feature is not selected, then the DRV10983 may be configured to either wait for the motor to stop spinning or brake the motor. After the motor has stopped spinning, the motor start-up sequence proceeds as it would for a motor which is stationary.

Take care when using the feature reverse drive or brake to ensure that the current is limited to an acceptable level and that the supply voltage does not surge as a result of energy being returned to the power supply.

图 **11. Start the Motor Under Different Initial Conditions**

8.4.3 Motor Start Sequence

图 [12](#page-20-0) shows the motor start sequence implemented in the DRV10983.

图 **12. Motor Starting-Up Flow**

- **Power-On State** This is the initial power-on state of the motor start sequencer (MSS). The MSS starts in this state on initial power-up or whenever the DRV10983 comes out of either standby or sleep modes.
- **ISDen Judgment** After power on, the DRV10983 MSS enters the ISDen Judgment where it checks to see if the Initial Speed Detect (ISD) function is enabled (ISDen = 1). If ISD is disabled, the MSS proceeds directly to the BrkEn Judgment. If ISD is enabled, the motor start sequence advances to the ISD state.
- **ISD State** The MSS determines the initial condition of the motor (see *[ISD](#page-21-0)*).
- **Speed<ISDThr Judgment** If the motor speed is lower than the threshold defined by ISDThr[1:0], then the motor is considered to be stationary and the MSS proceeds to the BrkEn judgment. If the speed is greater than the threshold defined by ISDThr[1:0], the start sequence proceeds to the Forward judgment.
- **Forward Judgment** The MSS determines whether the motor is spinning in the forward or the reverse direction. If the motor is spinning in the forward direction, the DRV10983 executes the resynchronization (see *Motor [Resynchronization](#page-22-0)*) process by transitioning directly into the ClosedLoop state. If the motor is spinning in the reverse direction, the MSS proceeds to the Speed>RvsDrThr.
- **Speed>RvsDrThr Judgment** The motor start sequencer checks to see if the reverse speed is greater than the threshold defined by RvsDrThr[2:0]. If it is, then the MSS returns to the ISD state to allow the motor to decelerate. This prevents the DRV10983 from attempting to reverse drive or brake a motor that is spinning too quickly. If the reverse speed of the motor is less than the threshold defined by RvsDrThr[2:0], then the MSS advances to the RvsDrEn judgment.
- **RvsDrEn Judgment** The MSS checks to see if the reverse drive function is enabled (RvsDrEn = 1). If it is, the MSS transitions into the RvsDr state. If the reverse drive function is not enabled, the MSS

advances to the BrkEn judgment.

- **RvsDr State** The DRV10983 drives the motor in the forward direction to force it to rapidly decelerate (see *[Reverse](#page-22-1) Drive*). When it reaches zero velocity, the MSS transitions to the Accelerate state.
- **BrkEn Judgment** The MSS checks to determine whether the brake function is enabled (BrkDoneThr[2:0] ≠ 000). If the brake function is enabled, the MSS advances to the Brake state.
- **Brake State** The device performs the brake function (see *Motor [Brake](#page-22-2)*).
- **Time>BrkDoneThr Judgment** The MSS applies brake for time configured by BRKDontThr[2:0]. After brake state, the MSS advances to the IPDEn judgment.
- **IPDEn Judgment** The MSS checks to see if IPD has been enabled (IPDCurrThr[3:0] ≠ 0000). If the IPD is enabled, the MSS transitions to the IPD state. Otherwise, it transitions to the align state.
- **Align State** The DRV10983 performs align function (see *[Align](#page-22-3)*). After the align completes, the MSS transitions to the Accelerate state.
- **IPD State** The DRV10983 performs the IPD function. The IPD function is described in *Initial [Position](#page-23-0) Detect [\(IPD\)](#page-23-0)* . After the IPD completes, the MSS transitions to the Accelerate state.
- **Accelerate State** The DRV10983 accelerates the motor according to the setting StAccel and StAccel2. After applying the accelerate settings, the MSS advances to the Speed > Op2ClsThr judgment.
- **Speed>Op2ClsThr Judgment** The motor accelerates until the drive rate exceeds the threshold configured by the Op2ClsThr[4:0] settings. When this threshold is reached, the DRV10983 enters into the ClosedLoop state.
- **ClosedLoop State** In this state, the DRV10983 drives the motor based on feedback from the commutation control algorithm.
- **DIR Pin Change Judgment** If DIR pin get changed during any of above states, DRV10983 stops driving the motor and restarts from the beginning.

8.4.3.1 ISD

The ISD function is used to identify the initial condition of the motor. If the function is disabled, the DRV10983 does not perform the initial speed detect function and treats the motor as if it is stationary.

Phase-to-phase comparators are used to detect the zero crossings of the BEMF voltage of the motor while it is coasting (motor phase outputs are in high-impedance state). $\mathbb{8}$ [13](#page-21-1) shows the configuration of the comparators.

图 **13. Initial Speed Detect Function**

If the UW comparator output is lagging the UV comparator by 60°, the motor is spinning forward. If the UW comparator output is leading the UV comparator by 60° , the motor is spinning in reverse.

The motor speed is determined by measuring the time between two rising edges of either of the comparators.

If neither of the comparator outputs toggle for a given amount of time, the condition is defined as stationary. The amount of time can be programmed by setting the register bits ISDThr[1:0].

8.4.3.2 Motor Resynchronization

The resynchronize function works when the ISD function is enabled and determines that the initial state of the motor is spinning in the forward direction. The speed and position information measured during ISD are used to initialize the drive state of the DRV10983, which can transition directly into the closed loop running state without needing to stop the motor.

8.4.3.3 Reverse Drive

The ISD function measures the initial speed and the initial position; the DRV10983 reverse drive function acts to reverse accelerate the motor through zero speed and to continue accelerating until the closed loop threshold is reached (see $\mathbb{8}$ [14\)](#page-22-4). If the reverse speed is greater than the threshold configured in RvsDrThr[1:0], then the DRV10983 waits until the motor coasts to a speed that is less than the threshold before driving the motor to reverse accelerate.

图 **14. Reverse Drive Function**

Reverse drive is suitable for applications where the load condition is light at low speed and relatively constant and where the reverse speed is low (that is, a fan motor with little friction). For other load conditions, the motor brake function provides a method for helping force a motor which is spinning in the reverse direction to stop spinning before a normal start-up sequence.

8.4.3.4 Motor Brake

The motor brake function can be used to stop the spinning motor before attempting to start the motor. The brake is applied by turning on all three of the low-side driver FETs.

Brake is enabled by configuring non zero value for BrkDoneThr[2:0]. Braking is applied for time configured by BrkDoneThr[2:0] (reverse or forward). After the motor is stopped, the motor position is unknown. To proceed with restarting in the correct direction, the IPD or Align and Go algorithm needs to be implemented. The motor start sequence is the same as it would be for a motor starting in the stationary condition.

The motor brake function can be disabled. The motor skips the brake state and attempts to spin the motor as if it were stationary. If this happens while the motor is spinning in either direction, the start-up sequence may not be successful.

8.4.3.5 Motor Initialization

8.4.3.5.1 Align

The DRV10983 aligns a motor by injecting dc current through a particular phase pattern which is current flowing into phase V, flowing out from phase W for a certain time (configured by AlignTime[2:0]). The current magnitude is determined by OpenLCurr[1:0]. The motor should be aligned at the known position.

The time of align affects the start-up timing (see *[Start-Up](#page-25-6) Timing*). A bigger inertial motor requires longer align time.

[DRV10983,](http://www.ti.com.cn/product/cn/drv10983?qgpn=drv10983) DRV10983Z

ZHCSDA7G –JULY 2014–REVISED FEBRUARY 2018 **www.ti.com.cn**

8.4.3.5.2 Initial Position Detect (IPD)

The inductive sense method is used to determine the initial position of the motor when IPD is enabled. IPD is enabled by selecting IPDCurrThr[3:0] to any value other than 0000.

IPD can be used in applications where reverse rotation of the motor is unacceptable. Because IPD does not need to wait for the motor to align with the commutation, it can allow for a faster motor start sequence. IPD works well when the inductance of the motor varies as a function of position. Because it works by pulsing current to the motor, it can generate acoustics which must be taken into account when determining the best start method for a particular application.

8.4.3.5.2.1 IPD Operation

The IPD operates by sequentially applying voltage across two of the three motor phases according to the following sequence: VW WV UV VU WU UW (see $\overline{8}$ [15\)](#page-23-1). When the current reaches the threshold configured in IPDCurrThr[3:0], the voltage across the motor is stopped. The DRV10983 measures the time it takes from when the voltage is applied until the current threshold is reached. The time varies as a function of the inductance in the motor windings. The state with the shortest time represents the state with the minimum inductance. The minimum inductance is because of the alignment of the north pole of the motor with this particular driving state.

8.4.3.5.2.2 IPD Release Mode

Two options are available for stopping the voltage applied to the motor when the current threshold is reached. If IPDRlsMd = 0, the recirculate mode is selected. The low-side (S6) MOSFET remains on to allow the current to recirculate between the MOSFET (S6) and body diode (S2) (see \mathbb{R} [16\)](#page-24-0). If IPDRIsMd = 1, the high-impedance (Hi-Z) mode is selected. Both the high-side (S1) and low-side (S6) MOSFETs are turned off and the current flies back across the body diodes into the power supply (see $\frac{8}{3}$ [17](#page-24-1)).

The high-impedance mode has a faster settle-down time, but could result in a surge on V_{CC} . Manage this with appropriate selection of either a clamp circuit or by providing sufficient capacitance between V_{CC} and GND. If the voltage surge cannot be contained and if it is unacceptable for the application, then select the recirculate mode. When selecting the recirculate mode, select the IPDC_{lk}[1:0] bits to give the current in the motor windings enough time to decay to 0.

图 **17. IPD Release Mode 1**

8.4.3.5.2.3 IPD Advance Angle

After the initial position is detected, the DRV10983 begins driving the motor at an angle specified by IPDAdvcAgl[1:0].

Advancing the drive angle anywhere from 0° to 180° results in positive torque. Advancing the drive angle by 90° results in maximum initial torque. Applying maximum initial torque could result in uneven acceleration to the rotor. Select the IPDAdvcAgl[1:0] to allow for smooth acceleration in the application (see \mathbb{R} [18](#page-24-2)).

8.4.3.5.3 Motor Start

After it is determined that the motor is stationary and after completing the motor initialization with either align or IPD, the DRV10983 begins to accelerate the motor. This acceleration is accomplished by applying a voltage determined by the open loop current setting (OpenLCurr[1:0]) to the appropriate drive state and by increasing the rate of commutation without regard to the real position of the motor (referred to as open loop operation). The function of the open loop operation is to drive the motor to a minimum speed so that the motor generates sufficient BEMF to allow the commutation control logic to accurately drive the motor.

 $\frac{1}{3}$ 4 lists the configuration options that can be set in register to optimize the initial motor acceleration stage for different applications.

8.4.3.6 Start-Up Timing

Start-up timing is determined by the align and accelerate time. The align time can be set by AlignTime[2:0], as described in *Register [Definition](#page-41-3)* . The accelerate time is defined by the open-to-closed loop threshold Op2ClsThr[4:0] along with the first order StAccel[2:0](A1) and second order StAccel2[2:0](A2) acceleration coefficient. $\sqrt{8}$ [19](#page-25-8) shows the motor start-up process.

图 **19. Motor Start-Up Process**

Select the first order and second order acceleration coefficient to allow the motor to reliably accelerate from zero velocity up to the closed loop threshold in the shortest time possible. Using a slow acceleration coefficient during the first order accelerate stage can help improve reliability in applications where it is difficult to accurately initialize the motor with either align or IPD.

Select the open-to-closed loop threshold to allow the motor to accelerate to a speed that generates sufficient BEMF for closed loop control. This is determined by the velocity constant of the motor based on the relationship described in [公式](#page-25-1) 2.

$$
BEMF = Kt \times speed (Hz)
$$
 (2)

8.4.4 Start-Up Current Setting

The start-up current setting is to control the peak start-up during open loop. During open loop operation, it is desirable to control the magnitude of drive current applied to the motor. This is helpful in controlling and optimizing the rate of acceleration. The limit takes effect during reverse drive, align, and acceleration.

The start current is set by programming the OpenLCurr[1:0] bits. The current should be selected to allow the motor to reliably accelerate to the handoff threshold. Heavier loads may require a higher current setting, but it should be noted that the rate of acceleration will be limited by the acceleration rate (StAccel[2:0], StAccel2[2:0]). If the motor is started with more current than necessary to reliably reach the handoff threshold, it results in higher power consumption.

The start current is controlled based on the relationship shown in [公式](#page-25-5) 3 and 图 [20](#page-26-0). The duty cycle applied to the motor is derived from the calculated value for U_{limit} and the magnitude of the supply voltage, V_{CC} , as well as the drive state of the motor.

 $U_{\text{Limit}} = I_{\text{Limit}} \times Rm + Speed (Hz) \times Kt$

where

I_{Limit} is configured by OpenLCurr[1:0]

- Rm is configured by Rm[6:0]
- Speed is variable based open-loop acceleration profile of the motor
- Kt is configured by $\mathsf{Kt}[\mathsf{6:0}]$ (3)

图 **20. Motor Start-Up Current**

8.4.4.1 Start-Up Current Ramp-Up

A fast change in the applied drive current may result in a sudden change in the driving torque. In some applications, this could result in acoustic noise. To avoid this, the DRV10983 allows the option of limiting the rate at which the current is applied to the motor. OpLCurrRt[2:0] sets the maximum voltage ramp up rate that will be applied to the motor. The waveforms in \mathbb{R} [21](#page-26-2) show how this feature can be used to gradually ramp the current applied to the motor.

Start driving with fast current ramp Start driving with slow current ramp

8.4.5 Closed Loop

In closed loop operation, the DRV10983 continuously samples the current in the U phase of the motor and uses this information to estimate the BEMF voltage that is present. The drive state of the motor is controlled based on the estimated BEMF voltage.

8.4.5.1 Half Cycle Control and Full Cycle Control

The estimated BEMF used to control the drive state of the motor has two zero-crosses every electrical cycle. The DRV10983 can be configured to update the drive state either once every electrical cycle or twice for every electrical cycle. When AdjMode is programmed to 1, half cycle adjustment is applied. The control logic is triggered at both rising edge and falling edge. When AdjMode is programmed to 0, full cycle adjustment is applied. The control logic is triggered only at the rising edge (see $\boxed{8}$ [22\)](#page-27-0).

Half cycle adjustment provides a faster response when compared with full cycle adjustment. Use half cycle adjustment whenever the application requires operation over large dynamic loading conditions. Use the full cycle adjustment for low current (<1 A) applications because it offers more tolerance for current measurement offset errors.

图 **22. Closed Loop Control Commutation Adjustment Mode**

8.4.5.2 Analog Mode Speed Control

The SPEED input pin can be configured to operate as an analog input (SpdCtrlMd = 0).

When configured for analog mode, the voltage range on the SPEED pin can be varied from 0 to V3P3. If SPEED > V_{ANA_FS} , the speed command is maximum. If V_{ANA_ZS} ≤ SPEED < V_{ANA_FS} the speed command changes linearly according to the magnitude of the voltage applied at the SPEED pin. If SPEED < $V_{\sf ANA_{ZS}}$ the speed command is to stop the motor. \mathbb{R} [23](#page-27-1) shows the speed command when operating in analog mode.

图 **23. Analog Mode Speed Command**

8.4.5.3 Digital PWM Input Mode Speed Control

If SpdCtrlMd = 1, the SPEED input pin is configured to operate as a PWM-encoded digital input. The PWM duty cycle applied to the SPEED pin can be varied from 0 to 100%. The speed command is proportional to the PWM input duty cycle. The speed command stops the motor when the PWM input keeps at 0 for t_{EN SL} _{PWM} (see [图](#page-28-0) [24](#page-28-0)).

The frequency of the PWM input signal applied to the SPEED pin is defined as f_{PWM} . This is the frequency the device can accept to control motor speed. It does not correspond to the PWM output frequency that is applied to the motor phase. The PWM output frequency can be configured to be either 25 kHz when the DoubleFreq bit is set to 0 or to 50 kHz when DoubleFreq bit is set to 1.

图 **24. PWM Mode Speed Command**

8.4.5.4 I ²C Mode Speed Control

The DRV10983 can also command the speed through the I^2C serial interface. To enable this feature, the OverRide bit is set to 1. When the DRV10983 is configured to operate in I²C mode, it ignores the signal applied to the SPEED pin.

The speed command can be set by writing the SpdCtrl[8] and SpdCtrl[7:0] bits. The 9-bit SpdCtrl [8:0] located in the SpeedCtrl1 and SpeedCntrl2 registers are used to set the peak amplitude voltage applied to the motor. The maximum speed command is set when SpdCtrl [8:0] is set to 0x1FF (511).

When SpdCtrl [8] is written to the SpeedCtrl2 register, the data is stored, but the output is not changed. When SpdCtrl [7:0] is written to the SpeedCtrl1 register, the speed command is updated (see $\boxed{8}$ [25\)](#page-28-4).

图 **25. I ²C Mode Speed Control**

8.4.5.5 Closed Loop Accelerate

To prevent sudden changes in the torque applied to the motor which could result in acoustic noise, the DRV10983 provides the option of limiting the maximum rate at which the speed command changes. ClsLpAccel[2:0] can be programmed to set the maximum rate at which the speed command changes (shown in 图 [26](#page-29-0)).

图 **26. Closed-Loop Accelerate**

8.4.5.6 Control Coefficient

The DRV10983 continuously measures the motor current and uses this information to control the drive state of the motor when operating in closed loop mode. In applications where noise makes it difficult to control the commutation optimally, the CtrlCoef[1:0] can be used to attenuate the feedback used for closed loop control. The loop will be less reactive to the noise on the feedback and provide for a smoother output.

8.4.5.7 Commutation Control Advance Angle

To achieve the best efficiency, it is often desirable to control the drive state of the motor so that the phase current of the motor is aligned with the BEMF voltage of the motor.

To align the phase current of the motor with the BEMF voltage of the motor, consider the inductive effect of the motor. The voltage applied to the motor should be applied in advance of the BEMF voltage of the motor (see [图](#page-29-1)) [27](#page-29-1)). The DRV10983 provides configuration bits for controlling the time (t_{adv}) between the driving voltage and BEMF.

For motors with salient pole structures, aligning the motor BEMF voltage with the motor current may not achieve the best efficiency. In these applications, the timing advance should be adjusted accordingly. Accomplish this by operating the system at constant speed and load conditions and by adjusting the t_{adv} until the minimum current is achieved.

图 **27. Advance Time (tadv) Definition**

The DRV10983 has two options for adjusting the motor commutate advance time. When CtrlAdvMd = 0, mode 0 is selected. When $CtrlAdvMd = 1$, mode 1 is selected.

Mode 0: t_{ady} is maintained to be a fixed time relative to the estimated BEMF zero cross as determined by [公式](#page-29-2) 4.

 $t_{\text{adv}} = t_{\text{SETTING}}$ (4)

Mode 1: t_{adv} is maintained to be a variable time relative to the estimated BEMF zero cross as determined by [公式](#page-29-3) [5.](#page-29-3)

 $t_{adv} = t_{SETTING} \times (U-BEMF)/U.$

where

- U is the phase voltage amplitude
- BEMF is phase BEMF amplitude (5)

t_{SETTING} (in µs) is determined by the configuration of the TCtrlAdv [6:4] and TCtrlAdv [3:0] bits as defined in 4π [6.](#page-30-1) For convenience, the available t_{SETTING} values are provided in $\frac{1}{36}$ 5.

 $t_{\text{SETTING}} = 2.5 \text{ }\mu\text{s} \times \text{[TCtrlAdv[3:0]]} << \text{TCtrlAdv[6:4]}$ (6)

表 **5. Configuring Commutation Advance Timing by Adjusting tSETTING**

8.4.6 Current Limit

The DRV10983 has several current limit modes to help ensure optimal control of the motor and to ensure safe operation. The various current limit modes are listed in $\frac{1}{36}$ 6. Acceleration current limit is used to provide a means of controlling the amount of current delivered to the motor. This is useful when the system needs to limit the amount of current pulled from the power supply during motor start-up. The lock detection current limit is a configurable threshold that can be used to limit the current applied to the motor. Overcurrent protection is used to protect the device; therefore, it cannot be disabled or configured to a different threshold. The current limit modes are described in the following sections.

表 **6. DRV10983 Current Limit Modes**

[DRV10983,](http://www.ti.com.cn/product/cn/drv10983?qgpn=drv10983) DRV10983Z

ZHCSDA7G –JULY 2014–REVISED FEBRUARY 2018 **www.ti.com.cn**

8.4.6.1 Acceleration Current Limit

The acceleration current limit limits the voltage applied to the motor to prevent the current from exceeding the programmed threshold. The acceleration current limit threshold is configured by writing the SWiLimitThr[3:0] bits to select I_{LIMIT} . The acceleration current limit does not use a direct measurement of current. It uses the programmed motor phase resistance, R_{PH_CT}, and programmed BEMF constant, Kt, to limit the voltage applied to the motor, U, as shown in $\frac{8}{8}$ [28](#page-31-2) and [公式](#page-31-3) 7.

When the acceleration current limit is active, it does not stop the motor from spinning nor does it trigger a fault. The acceleration current limit function is only available in closed loop control.

Copyright © 2017, Texas Instruments Incorporated

 $BEMF = Kt \times Speed$

ILIMIT

Rm

w٨

8.4.7 Lock Detect and Fault Handling

32

The DRV10983 provides several options for determining if the motor becomes locked as a result of some external torque. Five lock detect schemes work together to ensure the lock condition is detected quickly and reliably. 图 [29](#page-32-0) shows the logic which integrates the various lock detect schemes. When a lock condition is detected, the DRV10983 device takes action to prevent continuously driving the motor in order to prevent damage to the system or the motor.

图 **28. Acceleration Current Limit**

In addition to detecting if there is a locked motor condition, the DRV10983 also identifies and takes action if there is no motor connected to the system.

Each of the five lock-detect schemes and the no motor detection can be disabled by respective register bits LockEn[5:0].

When a lock condition is detected, the MtrLck in the Status register is set. The FaultCode register provides an indication of which of the six different conditions was detected on Lock5 to Lock0. These bits are reset when the motor restarts. The bits in the FaultCode register are set even if the lock detect scheme is disabled.

The DRV10983 reacts to either locked rotor or no motor connected conditions by putting the output drivers into a high-impedance state. To prevent the energy in the motor from pumping the supply voltage, the DRV10983 incorporates an anti-voltage-surge (AVS) process whenever the output stages transition into the high-impedance state. The AVS function is described in *AVS [Function](#page-34-0)*. After entering the high-impedance state as a result of a fault condition, the system tries to restart after $t_{\text{LOCK-OFF}}$.

 V_{U_LIMIT}

STRUMENTS

图 **29. Lock Detect and Fault Diagnose**

8.4.7.1 Lock0: Lock Detection Current Limit Triggered

The lock detection current limit function provides a configurable threshold for limiting the current to prevent damage to the system. This is often tripped in the event of a sudden locked rotor condition. The DRV10983 continuously monitors the current in the low-side drivers as shown in \boxtimes [30](#page-32-1). If the current goes higher than the threshold configured by the HWiLimitThr[2:0] bits, then the DRV10983 stops driving the motor by placing the output phases into a high-impedance state. The MtrLck bit is set and a lock condition is reported. It retries after t_{LOCK} OFF.

Set the lock detection current limit to a higher value than the acceleration current limit.

图 **30. Lock Detection Current Limit**

8.4.7.2 Lock1: Abnormal Speed

If motor is operating normally, the motor BEMF should always be less than output amplitude. The DRV10983 uses two methods of monitoring the BEMF in the system. The U phase current is monitored to maintain an estimate of BEMF based on the setting for Rm[6:0]. In addition, the BEMF is estimated based on the operation speed of the motor and the setting for Kt[6:0]. 图 [31](#page-33-0) shows the method for using this information to detect a lock condition. If motor BEMF is much higher than output amplitude for a certain period of time, t_{LCKETR} , it means the estimated speed is wrong, and the motor has gotten out of phase.

Lock Detected If BEMF2 $>$ V_U Copyright © 2017, Texas Instruments Incorporated

8.4.7.3 Lock2: Abnormal Kt

For any given motor, the integrated value of BEMF during half of an electrical cycle is constant. It is determined by BEMF constant (Kt) (see 图 [32\)](#page-33-1). It is true regardless of whether the motor is running fast or slow. This constant value is continuously monitored by calculation and used as criteria to determine the motor lock condition. It is referred to as Ktc.

Based on the Kt value programmed, create a range from Kt_low to Kt_high, if the Ktc goes beyond the range for a certain period of time, t_{LCK} ETR, lock is detected. Kt_low and Kt_high are determined by KtLckThr[1:0] (see [图](#page-33-2) [33](#page-33-2)).

图 **33. Abnormal Kt Lock Detect**

8.4.7.4 Lock3 (Fault3): No Motor Fault

The phase U current is checked after transitioning from open loop to closed loop. If phase U current is not greater than 140 mA then the motor is not connected as shown in \mathbb{R} [34.](#page-34-1) This condition is treated and reported as a fault.

图 **34. No Motor Error**

8.4.7.5 Lock4: Open Loop Motor Stuck Lock

Lock4 is used to detect locked motor conditions while the motor start sequence is in open loop.

For a successful startup, motor speed should equal to open to closed loop handoff threshold when the motor is transitioning into closed loop. However, if the motor is locked, the motor speed is not able to match the open loop drive rate.

If the motor BEMF is not detected for one electrical cycle after the open loop drive rate exceeds the threshold, then the open loop was unsuccessful as a result of a locked rotor condition.

8.4.7.6 Lock5: Closed Loop Motor Stuck Lock

If the motor suddenly becomes locked, motor speed and Ktc are not able to be refreshed because motor BEMF zero cross may not appear after the lock. In this condition, lock can also be detected by the following scheme: if the current commutation period is 2× longer than the previous period.

8.4.8 AVS Function

When a motor is driven, energy is transferred from the power supply into it. Some of this energy is stored in the form of inductive energy or as mechanical energy. The DRV10983 includes circuits to prevent this energy from being returned to the power supply which could result in pumping up the V_{CC} voltage. This function is referred to as the AVS and acts to protect the DRV10983 as well as other circuits that share the same V_{CC} connection. Two forms of AVS protection are used to prevent both the mechanical energy or the inductive energy from being returned to the supply. Each of these modes can be independently disabled through the register configuration bits AVSMEn and AVSIndEn.

8.4.8.1 Mechanical AVS Function

If the speed command suddenly drops such that the BEMF voltage generated by the motor is greater than the voltage that is applied to the motor, then the mechanical energy of the motor is returned to the power supply and the V_{CC} voltage surges. The mechanical AVS function works to prevent this from happening. The DRV10983 buffers the speed command value and limits the resulting output voltage, U_{MIN} , so that it is not less than the BEMF voltage of the motor. The BEMF voltage in the mechanical AVS function is determined using the programmed value for the Kt of the motor (Kt[6:0]) along with the speed. 图 [35](#page-34-2) shows the criteria used by the mechanical AVS function.

 V_U _{MIN} = BEMF + I_{MIN} × Rm = BEMF Copyright © 2017, Texas Instruments Incorporated

图 **35. Mechanical AVS**

The mechanical AVS function can operate in one of two modes, which can be configured by the register bit AVSMMd:

AVSMMd $= 0 - AVS$ mode is always active to prevent the applied voltage from being less than the BEMF voltage.

AVSMMd = 1 – AVS mode becomes active when V_{CC} reaches 24 V. The motor acts as a generator and returns energy into the power supply until V_{CC} reaches 24 V. This mode can be used to enable faster deceleration of the motor in applications where returning energy to the power supply is allowed.

8.4.9 PWM Output

The DRV10983 has 16 options for PWM dead time which can be used to configure the time between one of the bridge FETs turning off and the complementary FET turning on. Deadtime[3:0] can be used to configure dead times between 40 ns and 640 ns. Take care that the dead time is long enough to prevent the bridge FETs from shooting through. The recommend minimum dead time is 400 ns for 24-V VCC and 360 ns for 12-V VCC.

The DRV10983 offers two options for PWM switching frequency. When the configuration bit DoubleFreq is set to 0, the output PWM frequency will be 25 kHz and when DoubleFreq is set to 1, the output PWM frequency will be 50 kHz.

8.4.10 FG Customized Configuration

The DRV10983 provides information about the motor speed through the frequency generate (FG) pin. FG also provides information about the driving state of the DRV10983.

8.4.10.1 FG Output Frequency

The FG output frequency can be configured by FGcycle[1:0]. The default FG toggles once every electrical cycle (FGcycle = 00). Many applications configure the FG output so that it provides two pulses for every mechanical rotation of the motor. The configuration bits provided in DRV10983 can accomplish this for 4-pole, 6-pole, 8-pole, and 12-pole motors, as shown in $\overline{\mathbb{8}3}$ [36.](#page-35-2)

图 [36](#page-35-2) shows the DRV10983 has been configured to provide FG pulses once every electrical cycle (4 pole), twice every three electrical cycle (6 pole), once every two electrical cycles (8 pole), and once every three electrical cycles (12 pole).

Note that when it is set to 2 FG pulses every three electrical cycles, the FG output is not 50% duty cycle. Motor speed is able to be measured by monitoring the rising edge of the FG output.

图 **36. FG Frequency Divider**

8.4.10.2 FG Open-Loop and Lock Behavior

Note that the FG output reflects the driving state of the motor. During normal closed loop behavior, the driving state and the actual state of the motor are synchronized. During open loop acceleration, however, this may not reflect the actual motor speed. During a locked motor condition, the FG output is driven high.

The DRV10983 provides three options for controlling the FG output during open loop as shown in $\boxed{8\,}$ [37.](#page-36-0) The selection of these options is determined by the FGOLsel[1:0] setting.

- Option0: Open loop output FG based on driving frequency
- Option1: Open loop no FG output (keep high)
- • Option2: FG output based on driving frequency at the first power-on start-up, and no FG output (keep high) for any subsequent restarts

图 **37. FG Behavior During Open Loop**

8.4.11 Diagnostics and Visibility

The DRV10983 offers extensive visibility into the motor system operation conditions stored in internal registers. This information can be monitored through the I²C interface. Information can be monitored relating to the device status, motor speed, supply voltage, speed command, motor phase voltage amplitude, fault status, and others. The data is updated on the fly.

8.4.11.1 Motor Status Readback

The motor status register provides information on overtemperature (OverTemp), sleep or standby state (Slp_Stdby), over current (OverCurr), and locked rotor (MtrLck).

[DRV10983,](http://www.ti.com.cn/product/cn/drv10983?qgpn=drv10983) DRV10983Z

ZHCSDA7G –JULY 2014–REVISED FEBRUARY 2018 **www.ti.com.cn**

The motor operation speed is automatically updated in register MotorSpeed1 and MotorSpeed2 while the motor is spinning. MotorSpeed1 contains the 8 most significant bits and MotorSpeed2 contains the 8 least significant bits. The value is determined by the period for calculated BEMF zero crossings on phase U. The electrical speed of the motor is denoted as *Velocity (Hz)* and is calculated as shown in [公式](#page-37-0) 8. Velocity (Hz) = {MotorSpeed1:MotorSpeed2} / 10 (8)

As an example consider the following:

 $MotorSpeed1 = 0x01;$ MotorSpeed2 = 0xFF; Velocity = 512 (0x01FF) / 10 = 51 Hz

 $51 \frac{\text{ecycles}}{\text{second}} \times \frac{1}{2} \frac{\text{mechcycle}}{\text{ecycle}} \times 60 \frac{\text{second}}{\text{minute}} = 1530 \text{ RPM}$ \times 1 mechcycle \times 60 second $=$ For a 4-pole motor, this translates to:

8.4.11.2.1 Two-Byte Register Readback

Several of the registers such as MotorSpeed report data that is contained in two registers.

To make sure that the data does not change between the reading of the first and second register reads, the DRV10983 implements a special scheme to synchronize the reading of MSB and LSB data. To ensure valid data is read when reading a two register value, use the following sequence.

- 1. Read the MSB.
- 2. Read the LSB.

图 [38](#page-37-1) shows the two-register readback circuit. When the MSB is read, the controller takes a snapshot of the LSB. The LSB data is stored in one extra register byte, which is shown as MotorSpeedBuffer[7:0]. When the LSB is read, the value of MotorSpeedBuffer[7:0] is sent.

图 **38. Two-Byte Register Readback**

8.4.11.3 Motor Electrical Period Readback

The motor operation electrical period is automatically updated in register MotorPeriod1 and MotorPeriod2 while the motor is spinning. MotorPeriod1 is the MSB and MotorPeriod2 is the LSB. The electrical period is measured as the time between calculated BEMF zero crossings for phase U. The electrical period of the motor is denoted as d as t_{ELE} _{PERIOD} (µs) and is calculated as shown in [公式](#page-37-2) 9.

 $t_{E|E}$ $_{PERION}$ (µs) = {MotorPeriod1:MotorPeriod2} \times 10 (9)

As an example consider the following:

MotorPeriod1 = $0x01$; MotorPeriod2 = 0xFF: $t_{ELE~PERIOD} = 512 (0x01FF) \times 10 = 5120 \mu s$

The motor electrical period and motor speed satisfies the condition of $\Delta \vec{\mathbf{x}}$ 10.

 $t_{ELE\text{ PERIOD}}$ (s) \times Velocity (Hz) = 1 (10)

38

8.4.11.4 BEMF Constant Readback

For any given motor, the integrated value of BEMF during half of an electronic cycle will be constant, Ktc (see *Lock2: [Abnormal](#page-33-3) Kt*).

The integration of the motor BEMF is processed periodically (updated every electrical cycle) while the motor is spinning. The result is stored in register MotorKt1 and MotorKt2.

The relationship is shown in $\sqrt{\Delta} \vec{x}$ 11.

Ktc (V/Hz)= {MotorKt1:MotorKt2} / 2 /1090 (11)

8.4.11.5 Motor Estimated Position by IPD

After inductive sense is executed the rotor position is detected within 60 electrical degrees of resolution. The position is stored in register IPDPosition.

The value stored in IPD Position corresponds to one of the six motor positions plus the IPD Advance Angle as shown in [表](#page-38-1) 7. For more about information about IPD, see *Initial [Position](#page-23-0) Detect (IPD)*.

表 **7. IPD Position Readback**

8.4.11.6 Supply Voltage Readback

The power supply is monitored periodically during motor operation. This information is available in register SupplyVoltage. The power supply voltage is recorded as shown in $\Delta \vec{\pi}$ 12.

 $V_{\text{POWERSUPPLY}}(V) = \text{Supply Voltage} \times 30 \text{ V} / 256$ (12)

8.4.11.7 Speed Command Readback

The DRV10983 converts the various types of speed command into a speed command value (SpeedCmd) as shown in 图 [39.](#page-39-0) By reading SpeedCmd, the user can observe PWM input duty (PWM digital mode), analog voltage (analog mode), or I²C data (I²C mode). This value is calculated as shown in [公式](#page-38-3) 13.

[公式](#page-38-3) 13 shows how the speed command as a percentage can be calculated and set in SpeedCmd.

Duty $_{SPEED}$ (%) = SpeedCmd \times 100% / 255

where

- $Duty_{SPEED} = Speed command as a percentage$
- SpeedCmd = Register value (13)

8.4.11.8 Speed Command Buffer Readback

If acceleration current limit and AVS are enabled, the PWM duty cycle output (read back at spdCmdBuffer) may not always match the input command (read back at SpeedCmd) shown in 图 [39](#page-39-0). See *AVS [Function](#page-34-0)* and *[Current](#page-30-0) [Limit](#page-30-0)*.

By reading the value of spdCmdBuffer, the user can observe buffered speed command (output PWM duty cycle) to the motor.

EXAS ISTRUMENTS

[公式](#page-39-1) 14 shows how the buffered speed is calculated.

Duty_{OUTPUT} (%) = spdCmdBuffer \times 100% / 255

where

- Duty_{OUTPUT} = The maximum duty cycle of the output PWM, which represents the output amplitude in percentage.
- spdCmdBuffer = Register value (14)

图 **39. SpeedCmd and spdCmdBuffer Register**

8.4.11.9 Fault Diagnostics

See *Lock Detect and Fault [Handling](#page-31-0)*.

8.5 Register Maps

8.5.1 I ²C Serial Interface

The DRV10983 provides an I²C slave interface with slave address 101 0010. TI recommends a pullup resistor 4.7 kΩ to 3.3 V for I²C interface port SCL and SDA.

Four read/write registers (0x00:0x03) are used to set motor speed and control device registers and EEPROM. Device operation status can be read back through 12 read-only registers (0x10:0x1E). Another 12 EEPROM registers (0x20:0x2B) can be accessed to program motor parameters and optimize the spin-up profile for the application.

8.5.2 Register Map

(1) R/W
(2) Read

 (2) Read only
 (3) EEPROM EEPROM

表 **8. Default EEPROM Value**

8.5.3 Register Definition

表 **9. Register Description**

www.ti.com.cn ZHCSDA7G –JULY 2014–REVISED FEBRUARY 2018

表 **9. Register Description (**接下页**)**

[DRV10983,](http://www.ti.com.cn/product/cn/drv10983?qgpn=drv10983) DRV10983Z ZHCSDA7G –JULY 2014–REVISED FEBRUARY 2018 **www.ti.com.cn**

表 **9. Register Description (**接下页**)**

表 **9. Register Description (**接下页**)**

Register				
Name	Address	Bits	Data	Description
SysOpt3 ⁽³⁾	0x25	7:6	CtrlCoef[1:0]	Control coefficient $00 = 0.25$ $01 = 0.5$ $10 = 0.75$ $11 = 1$
		5:3	StAccel2[2:0]	Open loop start-up accelerate (second order) $000 = 57$ Hz/s ² $001 = 29$ Hz/s ² $010 = 14$ Hz/s ² $011 = 6.9$ Hz/s ² $100 = 3.3$ Hz/s ² $101 = 1.6$ Hz/s ² $110 = 0.66$ Hz/s ² $111 = 0.22$ Hz/s ²
		2:0	StAccel[2:0]	Open loop start-up accelerate (first order) $000 = 76$ Hz/s $001 = 38$ Hz/s $010 = 19$ Hz/s $011 = 9.2$ Hz/s $100 = 4.5$ Hz/s $101 = 2.1$ Hz/s $110 = 0.9$ Hz/s $111 = 0.3$ Hz/s
SysOpt4(3)	0x26	7:3	Op2ClsThr[4:0]	Open to closed loop threshold 0 xxxx = Range 0: n \times 0.8 Hz $00000 = N/A$ $00001 = 0.8$ Hz $00111 = 5.6$ Hz $01111 = 12$ Hz 1xxxx = Range 1: $(n + 1) \times 12.8$ Hz $10000 = 12.8$ Hz $10001 = 25.6$ Hz $10111 = 192$ Hz $11111 = 204.8$ Hz
		2:0	AlignTime[2:0]	Align time. $000 = 5.3$ s $001 = 2.7$ s $010 = 1.3$ s $011 = 0.67$ s $100 = 0.33$ s $101 = 0.16$ s $110 = 0.08$ s $111 = 0.04$ s
SysOpt5 ⁽³⁾	0x27	$\overline{7}$	FaultEn3 (LockEn[3])	No motor fault. Enabled when high
		6	LockEn[2]	Abnormal Kt. Enabled when high
		5	LockEn[1]	Abnormal speed. Enabled when high
		4	LockEn[0]	Lock detection current limit. Enabled when high
		3	AVSIndEn	Inductive AVS enable. Enabled when high.
		2	AVSMEn	Mechanical AVS enable. Enabled when high
		1	AVSMMd	Mechanical AVS mode $0 = AVS$ to V_{CC} $1 = AVS$ to 24 V
		0	IPDRISMd	IPD release mode $0 =$ Brake when inductive release $1 = Hi-z$ when inductive release

[DRV10983,](http://www.ti.com.cn/product/cn/drv10983?qgpn=drv10983) DRV10983Z ZHCSDA7G –JULY 2014–REVISED FEBRUARY 2018 **www.ti.com.cn**

9 Application and Implementation

注

Information in the following applications sections is not part of the TI component specification, and TI does not warrant its accuracy or completeness. TI's customers are responsible for determining suitability of components for their purposes. Customers should validate and test their design implementation to confirm system functionality.

9.1 Application Information

The DRV10983 is used in sensorless 3-phase BLDC motor control. The driver provides a high performance, high reliability, flexible and simple solution for appliance fan, pump, and HVAC applications. The following design in [图](#page-46-4) [40](#page-46-4) shows a common application of the DRV10983. For the DRV10983Z sleep mode device, a Zener diode must be placed in parallel with the 10-µF V_{REG} capacitor as shown in \mathbb{R} [40.](#page-46-4) The Zener diode must meet the requirements listed in 表 [11](#page-47-4)

9.2 Typical Application

图 **40. Typical Application Schematics for DRV10983 (Top Image) and DRV10983Z (Bottom Image)**

Typical Application (接下页**)**

9.2.1 Design Requirements

 $\frac{1}{3}$ [10](#page-47-5) provides design input parameters and motor parameters for system design.

表 **11. External Components**

9.2.2 Detailed Design Procedure

- 1. See the *Design [Requirements](#page-47-6)* section and make sure your system meets the recommended application range.
- 2. See the *DRV10983 and [DRV10975](http://www.ti.com/cn/lit/pdf/SLOU395) Tuning Guide* and measure the motor parameters.
- 3. See the *[DRV10983](http://www.ti.com/cn/lit/pdf/SLOU395) and DRV10975 Tuning Guide*. Configure the parameters using DRV10983 GUI, and optimize the motor operation. The *Tuning Guide* takes the user through all the configurations step by step, including: start-up operation, closed-loop operation, current control, initial positioning, lock detection, and anti-voltage surge.
- 4. See the *[Programming](http://www.ti.com/cn/lit/pdf/SLVUAA5) Guide for the DRV10983* and [Non-Volatile](#page-15-5) Memory section for burning tuned settings into EEPROM.
- 5. Build your hardware based on *Layout [Guidelines](#page-48-2)*.
- 6. Connect the device into system and validate your system solution.

9.2.3 Application Curves

10 Power Supply Recommendations

The DRV10983 is designed to operate from an input voltage supply, $V_{(VCC)}$, range between 8 V and 28 V. The user must place a 10-µF ceramic capacitor rated for V_{CC} as close as possible to the V_{CC} and GND pins.

If the power supply ripple is more than 200 mV, in addition to the local decoupling capacitors, a bulk capacitance is required and must be sized according to the application requirements. If the bulk capacitance is implemented in the application, the user can reduce the value of the local ceramic capacitor to 1 μ F.

11 Layout

11.1 Layout Guidelines

- Place V_{CC} , GND, U, V, and W pins with thick traces because high current passes through these traces.
- Place the 10-µF capacitor between V_{CC} and GND, and as close to the V_{CC} and GND pins as possible.
- Place the capacitor between CPP and CPN, and as close to the CPP and CPN pins as possible.
- Connect the GND, PGND, and SWGND under the thermal pad.
- Keep the thermal pad connection as large as possible, both on the bottom side and top side. It should be one piece of copper without any gaps.

[DRV10983,](http://www.ti.com.cn/product/cn/drv10983?qgpn=drv10983) DRV10983Z

ZHCSDA7G –JULY 2014–REVISED FEBRUARY 2018 **www.ti.com.cn**

11.2 Layout Example

图 **43. Layout Schematic**

12 器件和文档支持

12.1 器件支持

12.1.1 Third-Party Products Disclaimer

TI'S PUBLICATION OF INFORMATION REGARDING THIRD-PARTY PRODUCTS OR SERVICES DOES NOT CONSTITUTE AN ENDORSEMENT REGARDING THE SUITABILITY OF SUCH PRODUCTS OR SERVICES OR A WARRANTY, REPRESENTATION OR ENDORSEMENT OF SUCH PRODUCTS OR SERVICES, EITHER ALONE OR IN COMBINATION WITH ANY TI PRODUCT OR SERVICE.

12.2 文档支持

12.2.1 相关文档

如需相关文档,请参阅:

- 德州仪器 (TI),*DRV10983* 和 *[DRV10975](http://www.ti.com/cn/lit/pdf/SLOU393)* 评估模块用户指南
- 德州仪器 (TI),*DRV10983* 和 *[DRV10975](http://www.ti.com/cn/lit/pdf/SLOU395)*调优指南
- 德州仪器 (TI), [如何设计高效散热型集成](http://www.ti.com/cn/lit/pdf/SLVA938) *BLDC* 电机驱动 *PCB* 应用报告
- 德州仪器 (TI),*[DRV10983](http://www.ti.com/cn/lit/pdf/SLVUAA5)* 编程指南
- 德州仪器 (TI),交流*/*直流供电的 *BLDC* [应用中的速度控制](http://www.ti.com/cn/lit/pdf/SLOA203)应用报告

12.3 商标

PowerPAD, E2E are trademarks of Texas Instruments. All other trademarks are the property of their respective owners.

12.4 静电放电警告

这些装置包含有限的内置 ESD 保护。 存储或装卸时, 应将导线一起截短或将装置放置于导电泡棉中, 以防止 MOS 门极遭受静电损

12.5 接收文档更新通知

要接收文档更新通知, 请导航至 TI.com 上的器件产品文件夹。请单击右上角的提醒我 进行注册, 即可每周接收产 品信息更改摘要。有关更改的详细信息,请查看任何已修订文档中包含的修订历史记录。

12.6 社区资源

下列链接提供到 TI 社区资源的连接。链接的内容由各个分销商"按照原样"提供。这些内容并不构成 TI 技术规范, 并且不一定反映 TI 的观点:请参阅 TI 的 [《使用条款》。](http://www.ti.com/corp/docs/legal/termsofuse.shtml)

TI E2E™ [在线社区](http://e2e.ti.com) *TI* 的工程师对工程师 *(E2E)* 社区。此社区的创建目的在于促进工程师之间的协作。在 e2e.ti.com 中,您可以咨询问题、分享知识、拓展思路并与同行工程师一道帮助解决问题。

[设计支持](http://support.ti.com/) *TI* 参考设计支持 可帮助您快速查找有帮助的 E2E 论坛、设计支持工具以及技术支持的联系信息。

12.7 Glossary

[SLYZ022](http://www.ti.com/cn/lit/pdf/SLYZ022) — *TI Glossary*.

This glossary lists and explains terms, acronyms, and definitions.

13 机械、封装和可订购信息

以下页面包含机械、封装和可订购信息。这些信息是适用于指定器件的最新数据。数据如有变更,恕不另行通知和 修订此文档。要获取数据表的浏览器版本,请查看左侧的导航面板。

PACKAGING INFORMATION

(1) The marketing status values are defined as follows:

ACTIVE: Product device recommended for new designs.

LIFEBUY: TI has announced that the device will be discontinued, and a lifetime-buy period is in effect.

NRND: Not recommended for new designs. Device is in production to support existing customers, but TI does not recommend using this part in a new design.

PREVIEW: Device has been announced but is not in production. Samples may or may not be available.

OBSOLETE: TI has discontinued the production of the device.

⁽²⁾ RoHS: TI defines "RoHS" to mean semiconductor products that are compliant with the current EU RoHS requirements for all 10 RoHS substances, including the requirement that RoHS substance do not exceed 0.1% by weight in homogeneous materials. Where designed to be soldered at high temperatures, "RoHS" products are suitable for use in specified lead-free processes. TI may reference these types of products as "Pb-Free".

RoHS Exempt: TI defines "RoHS Exempt" to mean products that contain lead but are compliant with EU RoHS pursuant to a specific EU RoHS exemption.

Green: TI defines "Green" to mean the content of Chlorine (CI) and Bromine (Br) based flame retardants meet JS709B low halogen requirements of <=1000ppm threshold. Antimony trioxide based flame retardants must also meet the <=1000ppm threshold requirement.

(3) MSL, Peak Temp. - The Moisture Sensitivity Level rating according to the JEDEC industry standard classifications, and peak solder temperature.

(4) There may be additional marking, which relates to the logo, the lot trace code information, or the environmental category on the device.

(5) Multiple Device Markings will be inside parentheses. Only one Device Marking contained in parentheses and separated by a "~" will appear on a device. If a line is indented then it is a continuation of the previous line and the two combined represent the entire Device Marking for that device.

⁽⁶⁾ Lead/Ball Finish - Orderable Devices may have multiple material finish options. Finish options are separated by a vertical ruled line. Lead/Ball Finish values may wrap to two lines if the finish value exceeds the maximum column width.

Important Information and Disclaimer:The information provided on this page represents TI's knowledge and belief as of the date that it is provided. TI bases its knowledge and belief on information provided by third parties, and makes no representation or warranty as to the accuracy of such information. Efforts are underway to better integrate information from third parties. TI has taken and

www.ti.com 6-Feb-2020

continues to take reasonable steps to provide representative and accurate information but may not have conducted destructive testing or chemical analysis on incoming materials and chemicals. TI and TI suppliers consider certain information to be proprietary, and thus CAS numbers and other limited information may not be available for release.

In no event shall TI's liability arising out of such information exceed the total purchase price of the TI part(s) at issue in this document sold by TI to Customer on an annual basis.

PACKAGE MATERIALS INFORMATION

Texas
Instruments

TAPE AND REEL INFORMATION

QUADRANT ASSIGNMENTS FOR PIN 1 ORIENTATION IN TAPE

TEXAS
INSTRUMENTS

PACKAGE MATERIALS INFORMATION

www.ti.com 26-Feb-2019

*All dimensions are nominal

GENERIC PACKAGE VIEW

PWP 24 PWP 24 PowerPAD[™] TSSOP - 1.2 mm max height

4.4 x 7.6, 0.65 mm pitch PLASTIC SMALL OUTLINE

This image is a representation of the package family, actual package may vary. Refer to the product data sheet for package details.

PACKAGE OUTLINE

PWP0024B PowerPAD TSSOP - 1.2 mm max height TM

PLASTIC SMALL OUTLINE

NOTES:

PowerPAD is a trademark of Texas Instruments.

- 1. All linear dimensions are in millimeters. Any dimensions in parenthesis are for reference only. Dimensioning and tolerancing per ASME Y14.5M.
- 2. This drawing is subject to change without notice.
- 3. This dimension does not include mold flash, protrusions, or gate burrs. Mold flash, protrusions, or gate burrs shall not exceed 0.15 mm per side.
- 4. Reference JEDEC registration MO-153.
- 5. Features may not be present and may vary.

EXAMPLE BOARD LAYOUT

PWP0024B PowerPAD TSSOP - 1.2 mm max height TM

PLASTIC SMALL OUTLINE

NOTES: (continued)

6. Publication IPC-7351 may have alternate designs.

- 7. Solder mask tolerances between and around signal pads can vary based on board fabrication site.
- 8. This package is designed to be soldered to a thermal pad on the board. For more information, see Texas Instruments literature numbers SLMA002 (www.ti.com/lit/slma002) and SLMA004 (www.ti.com/lit/slma004).
- 9. Size of metal pad may vary due to creepage requirement.

EXAMPLE STENCIL DESIGN

PWP0024B PowerPAD TSSOP - 1.2 mm max height TM

PLASTIC SMALL OUTLINE

NOTES: (continued)

11. Board assembly site may have different recommendations for stencil design.

^{10.} Laser cutting apertures with trapezoidal walls and rounded corners may offer better paste release. IPC-7525 may have alternate design recommendations.

重要声明和免责声明

TI 均以"原样"提供技术性及可靠性数据(包括数据表)、设计资源(包括参考设计)、应用或其他设计建议、网络工具、安全信息和其他资 源,不保证其中不含任何瑕疵,且不做任何明示或暗示的担保,包括但不限于对适销性、适合某特定用途或不侵犯任何第三方知识产权的暗示 担保。

所述资源可供专业开发人员应用TI 产品进行设计使用。您将对以下行为独自承担全部责任:(1) 针对您的应用选择合适的TI 产品;(2) 设计、 验证并测试您的应用;(3) 确保您的应用满足相应标准以及任何其他安全、安保或其他要求。所述资源如有变更,恕不另行通知。TI 对您使用 所述资源的授权仅限于开发资源所涉及TI 产品的相关应用。除此之外不得复制或展示所述资源,也不提供其它TI或任何第三方的知识产权授权 许可。如因使用所述资源而产生任何索赔、赔偿、成本、损失及债务等,TI对此概不负责,并且您须赔偿由此对TI 及其代表造成的损害。

TI 所提供产品均受TI 的销售条款 [\(http://www.ti.com.cn/zh-cn/legal/termsofsale.html](http://www.ti.com.cn/zh-cn/legal/termsofsale.html)) 以及[ti.com.cn](http://www.ti.com.cn)上或随附TI产品提供的其他可适用条款的约 束。TI提供所述资源并不扩展或以其他方式更改TI 针对TI 产品所发布的可适用的担保范围或担保免责声明。

> 邮寄地址: 上海市浦东新区世纪大道 1568 号中建大厦 32 楼, 邮政编码: 200122 Copyright © 2020 德州仪器半导体技术(上海)有限公司